



SaniLite™

User Guide 01010

- Please read the following instructions and warnings carefully.
- Keep these instructions for future reference.
- Tool needed: Phillips Head Screwdriver (not included).
- Requires 4 AA batteries (not included).


Set-up and Use of your SaniLite™

1 Install Batteries:

Remove the battery compartment cover with a Phillips Head Screwdriver (not included) and insert four (4) AA batteries (not included). Make sure batteries align properly to the correct positive "+" and negative "-" polarity marked in the battery compartment. Replace the battery compartment cover. The SaniLite is ready to use.

2 Using your SaniLite:

- Hold the SaniLite facing down, press and hold the Power On/Off Button for two (2) seconds, Power On Indicator and UV-C Light will come on.
- Shine light on desired area and hold no further than one-half inch (1/2") above the surface and slowly move the SaniLite over a 12-inch area for 20 seconds. Continue until the desired surface is covered (refer to diagram below).
- To turn off, press the Power On/Off Button, the Power On Indicator and UV-C Light will go off.



IMPORTANT:

- To prevent eye and skin exposure, this product is equipped with an internal safety switch that will automatically turn the UV-C Light off when the product has been turned over (bulb facing up). The UV-C Light will resume working when turned back in the working position (bulb facing down).

Note: The internal safety switch may make a rattling sound, this is a normal function.

To conserve battery life, the SaniLite will automatically switch off after approximately 10 minutes. If additional use is required, simply turn On the product again.

Low Battery Indicator:

- The Power On LED light will flash indicating that the batteries require replacement.

Care and Maintenance

Cleaning

- Surface wash **ONLY** with a damp cloth to keep your SaniLite free from dust.
- **DO NOT** immerse product in water.

Storage

- Remove batteries before storing.
- Store out of reach of children in a safe, dry location.

Troubleshooting

Problem

The product will not turn on

Solution

Make sure batteries are installed correctly and the UV-C light is facing down.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Consumer Support

Baby's Journey stands behind all of its products. If you are not completely satisfied or have any questions, please contact our Consumer Care Team at 1-855-422-2975 or email us at wecare@babysjourney.com.

For replacement parts information or to view the Baby's Journey family of products visit www.babysjourney.com.

Baby's Journey, Inc.
999 Main St, #703
Pawtucket, RI 02860
1-855-422-2975
www.babysjourney.com

Product and design are TM and/
©2013 Baby's Journey, Inc.
Made in China
Colors and styles may vary.
Please retain for future reference.

1/9/13

Important Safety Warnings

! WARNING!

- Do not expose eyes and skin to UV light. Extended exposure of eyes or skin to UV light bulb can cause serious skin burn and eye inflammation from short wave ultraviolet radiation.
- This product is not a toy. Not to be handled by children.
- ALWAYS turn product off after each use. DO NOT leave product unattended while On.
- NEVER use this product on pets, people, food or plants.
- ALWAYS handle product with care to prevent bulb breakage.
- DO NOT use product if it is damaged or broken.

! BATTERY WARNING!

- ALWAYS keep batteries away from children.
- Any battery may leak if mixed with a different battery type, installed incorrectly or if all batteries are not replaced or recharged at the same time. Never mix old and new batteries. Never mix battery types such as alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium).
- Any battery may leak or explode if discarded or if an attempt is made to charge a battery not intended to be recharged.
- Discard leaky batteries immediately to avoid skin burns or other personal injury. Discard batteries properly according to local regulations.
- ALWAYS remove batteries if you do not intend to use the product for an extended period of time. Batteries left in the unit may leak and cause damage.
- Alkaline disposable batteries are recommended. Never mix battery types. Change batteries when unit no longer functions properly.

Features & Components

On/Off Button

Power On Indicator

UV-C Light

Battery Compartment

