




Set-up and Use of your BabySitter™

Step 1: Shoulder Harness Fit


The Shoulder Straps should fit at or slightly above shoulder height for maximum support and comfort. For most babies under 10 months, the lower set of slots 1 is suitable to start. As your child grows, check the height of the Adjustable Shoulder Straps to ensure proper fit. If further adjustment is needed, unclip the Adjustable Shoulder Straps and insert straps through upper slots 2.



Step 2: Assembly to Chair

Place Chair Back Support Strap over chair back and place the BabySitter flat on the chair. The Shoulder Straps should already be in place.

Wrap and secure the lower Support Strap around the chair and thread through one of the lower loops on the Chair Back Support Strap 3, repeat for upper Support Strap 4. Adjust the Support Straps by pulling the loose end of the strap away from the buckle.



Ensure that the Support Straps around the chair are snug, and the BabySitter sits flat on the chair, in order to provide security and support.

Step 3: Positioning Baby

Place child on the BabySitter as far back on the seat as possible and bring the Lap Support Pad between the child's legs. Attach each end of the Shoulder Strap to the small front buckles and adjust the plastic slides on the Shoulder Straps to lengthen/shorten as needed.

Attach each end of the Lap Support Strap to the small side buckles and adjust the plastic slides on the Lap Support Strap to lengthen/shorten as needed.

Ensure that these straps around the child are snug, and the BabySitter sits flat on the chair, in order to provide proper security and support.



Important Safety Warnings

! WARNING!

- Prevent serious injury or death from falls or sliding out.
- Always secure child in the restraint.
- Never leave child unattended.
- The child should be secured in the product at all times by the restraining system.
- ONLY use with children capable of sitting upright unassisted.
- ONLY use as intended. DO NOT use in motor vehicles, or any other transportation devices.
- NEVER allow a child to push away from table.
- NEVER allow child to stand up while using this product.
- ALWAYS check security of fit to adult chair before each use and any limitations of the product.
- ALWAYS secure the product to the adult chair by correctly using the fastening straps, see instructions. Adult chair must be level, stable and structurally sound with minimum seat surface dimensions of 16 inches and a minimum back rest of 18 inches.
- ALWAYS inspect product for signs of wear and tear, discontinue use of product if damaged or broken.
- This product is not a substitute for responsible adult supervision. ALWAYS use under adult supervision.

Consumer Support

Baby's Journey stands behind all of its products. If you are not completely satisfied or have any questions, please contact our Consumer Care Team at 1-855-422-2975 or email us at wecare@babysjourney.com.

For replacement parts information or to view the Baby's Journey family of products visit www.babysjourney.com.

Baby's Journey, Inc.
999 Main St, #703
Pawtucket, RI 02860
1-855-422-2975
www.babysjourney.com

Product and design are TM and/
©2013 Baby's Journey, Inc.
Made in China
Colors and styles may vary.
Please retain for future reference.

BabySitter™

User Guide

03020

- Please read the following instructions and warnings carefully before use of this product.
- Keep these instructions for future reference.
- For use with children from 6 months* - 2 years.
*ONLY use with children capable of sitting upright unassisted.


Features and Components

Cushioned Seat Pad

Adjustable Shoulder Straps


Adjustable Lap Straps

Lap Support Pad



Chair Back Support Strap

Support Straps



Care and Maintenance

Cleaning

- Secure closures before washing. Machine wash cold separately, gentle cycle. Do not bleach. Dry flat. Do not iron.